# IWBS 2004 Workshop Presentation Setup

Speaker
Presentation Monitor
(signal identical to beamer)

Additional wireless USB
"mouse" with 2 buttons
(← Slide →)

13 Min.

VGA

Speaker Timer
(monitor only)

RJ45 PC

VGA

Only the VGA output on the KVM* extender is needed in this setup

USB

USB

Antenna

USB

KVM* Extender

RJ45

USB Extender
(4xUSB)

RJ45

## Speaker (Stage)

## Chairman's Desk

CAT 5 Cable
(up to 100 m)

CAT 5 Cable
(up to 100 m)

CAT 5 Cable
(TCP/IP)

X

Beamer

KVM* Extender

RJ45

USB Extender

RJ45

Monitor Cable VGA
(ev. BNC R/G/B)

VGA

USB

KVM* Switch (4 inputs)
● = selected input "B" (example ABC)
Operated by Chairman

USB and VGA →

RJ45

Hub

123

ABC

(spare)

(spare)

VGA

PC

2x

13 Min.

Network

Laptop
WIN XP

Laptop
WIN XP

All presentations run on these laptops. Laptops are connected to the (conference/workshop) network (LAN) for downloading presentations.

USB

PS/2

*) KVM = Keyboard/Video/Mouse

Speaker Timer (Master)
Operated by Chairman

Martin Heiniger martin.heiniger@psi.ch December 1, 2004